



NOTES:

POWER TO TERMINALS ONE & TWO OPENS THE VALVE (CCW ROTATION)

POWER TO TERMINALS ONE & THREE CLOSES THE VALVE (CW ROTATION)

TERMINAL 4 SUPPLIES 120V HOT TO BRAKE.

TERMINALS 5 THROUGH 10 FOR AUXILIARY SWITCH CONNECTIONS

WIRING DIAGRAM ILLUSTRATES THE ACTUATOR IN THE OPEN POSITION

THIS IS A FAIL-SAFE ACTUATOR DO NOT USE IN CONTROL TYPE APPLICATIONS

----- OPTIONAL

————— FIELD WIRING

<i>I C I</i> Indelac Controls, Inc. Hebron, Ky. 41048	WIRING DIAGRAM FOR SPRING RETURN ELECTRIC ACTUATOR WITH TWO AUXILIARY SWITCHES.	JLR 9-10-99
	990910	

Spring Return Actuators